

PA450 series test adapter

Features

Application

- Desk housing with ergonomic bevel
- Pneumatic hold-down mechanism for contacting with PCBs up to 300 x 215 mm
- Contact from below, above or both sides
- Available without hold-down mechanism for EOL testing of modules and devices
- Optional: pneumatic opening and closing of the hold-down frame



Adapter housing with hold-down mechanism



Adapter housing without hold-down mechanism

- PCB contact with spring contact pins
- Installation of sensors and scanners
- Lateral contacting of connectors
- Connection of devices with quick release or pneumatics

As a systems manufacturer, we offer a wide range of test fixtures, from basic contactors to complex special designs - all from one provider. Visit our homepage to learn more.

PA450 with a Guardian Test System






PA450 series test adapter

Order information		
Description	Item no.	Compatible with Guardian System
PA450 blue desk housing with black, antistatic cover and pneumatic spring	13000	
Rear panel with Guardian interface	13006	х
Rear panel without recesses	13004	
PA450-N with pneumatic hold-down mechanism, Guardian System interface and two-hand control	21253	
PA450-NW with pneumatic hold-down mechanism and changing interface	21293	
Needle carrier plate made from hard paper 320x255x10mm, white-coated	13008	х
Needle carrier plate made from polycarbonate 309.5x224.5x8mm	13010	
Needle carrier plate for alternating system PA450-W with 288-pole contact strip, incl. protective plate on 4 distance bolts	13015	
Extension of automatic opening and closing of the hold-down bracket frame with pneumatic cylinder, solenoid valve and 2 end position sensors	21298	

Customizing

We offer DUT-specific test adapters as a service.

- Import your PCB data
- CNC processed adapter plates
- Use of sleeves and spring contact pins
- Installation of rigid or spring-loaded positioning pins
- Installation of hold-down pins.
- Contacting connectors
- Installation of components and wiring



Application example 1
Contacting of a DUT connector with a pneumatic needle nest.



Application example 2 PA450-N with DUT, contacting from below

We look forward to hearing from you!